



PURE FLOORING SOURCE

VINYL FLOOR MAINTENANCE GUIDE

MAINTENANCE, TIPS, AND WARNINGS FOR LVT

MAINTENANCE:

Dust-mop or broom can be used for daily maintenance. When necessary, clean with a MOIST cloth or mop and a light detergent.

NEVER USE floor polish or floor cleaning wax, oil soaps, etc. These products can damage and/or leave a film on the flooring.

TIPS:

Use felt tip protectors on all furniture legs/feet

Entryway/walk off mats are recommended; Warning: Never use rubber protective mats.

Area rugs are recommended

Keep pet nails trimmed

Sharp shoe-heels (eg. high-heels) may dent the floors

Never slide furniture across floor without pads

Keep floors clean

WARRANTY:

This LVT flooring is warranted to be free of defects in material and workmanship. All planks MUST be examined thoroughly PRIOR to installation and any questionable planks shall not be installed. It is important that the product be installed correctly and maintained properly. The warranty covers finish, wear resistance and stain resistance under normal conditions for interior use only. If you are installing this flooring in a medium or heavy commercial setting please obtain clearance from the manufacturer prior to installation. In the event of a claim, Seller reserves the right to either repair or replace product. The warranty covers the cost of the product only. All claims must be submitted in writing to place of purchase.

Failure to follow these procedures may result in voiding some or all of the warranty. This limited warranty is not transferable and extends only to the original end user.

Please note:

Some jurisdictions do not allow exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitation and exclusion may not apply to you. This warranty gives you specific rights and you may also have other rights, which vary from state to state.